

How to Install Nutserts

1/4" Nutserts

- Remove pad from machine
- Measure bolt pattern on pad
- Double check measurements of bolt pattern with holes on frame.
- Drill with 5/16" wood spade bit
- Install using a 6 mm Hex key.
- Should be flush. Do not over tighten.

5/16" Nutserts

- Remove pad from machine
- Measure bolt pattern on pad
- Double check measurements of bolt pattern with holes on frame.
- Drill with 7/16" wood spade bit
- Install using an 8 mm Hex key.
- Should be flush. Do not over tighten.