



How to Install Grips with Grip Cap



- Slice off old grip with razor blade.
- Remove Grip cap. If grip cap screws are stripped or hard to remove, grip cap should be replaced.
- Make sure bar is clean and dry.



- Spray bar and the inside of the grip with 1 squirt of hairspray. Do not use too much.
 - Slide grip onto bar while hairspray is still wet.
- Note: PVC grips will stretch during installation. Once grip is on bar be sure to pull the grip back towards the end of the bar slightly before cutting to insure grip does not shrink.



- Cut excess grip off, approximately 1/2" from end of bar.
- Install grip cap. Allow to sit for 10 - 15 minutes before using.



How to Install Grips without grip cap



- Slice off old grip with razor blade. Make sure bar is clean and dry.
- Cut new grip to size if needed.



- Spray bar and the inside of the grip with 1 squirt of hairspray. Do not use too much.

Note: PVC grips will stretch during installation. Once grip is on bar be sure to pull the grip back towards the end of the bar slightly to insure grip does not shrink.



- Slide grip onto bar while hairspray is still wet. Allow to sit for 10 - 15 minutes before using bar.